


Guest Room Butler Wiring Guide


ACT-05RDL


Overview



Guest Room Butler Wiring

Basic wiring






Bedside switch panel and curtain motor


Bedside switch panel

Multiple switch panels can be connected in a "daisy - chain" manner.



AOK Motor


RJ11 connector: Use 6P6C. Wiring: 1B Orange - white, 6A Orange



Connector of the bedside switch panel

DOOYA Motor

RJ11 connector: Use 4P4C Wiring: 3B Orange - white, 4A Orange



Wiring of the Sensor Gateway

Infrared emission module tis used for , projectors and fluorine - based air conditioners.

Infrared emission module: Connect to [Sensor Gateway] [PBUS+] 3








The model is **IR-S01** for air The model is **IR-L10** for projector

1. The direction indicated by the arrow is the infrared receiver of the TV or air conditioner.





Other switch panels

Connect to the sensor gateway (PBUS+)

Multiple switch panels can be connected in a "daisy - chain" manner. 4




Switch panel connection

Bedside switch panel connector

Human presence sensor

Human presence sensor: Connect to [Sensing Gateway] [P - BUS] 3





V+	blue - white
Α	orange
В	orange - white
V-	blue

Cutout size 40mm


When multiple human presence sensors and/or multiple 485 infrared sensors are connected, the "daisy - chain" method is adopted.



Infrared detector

485 Infrared Detector: Connect to [Sensor Gateway] [P - BUS]





VCC	blue - white
GND	blue
А	orange
В	orange - white

Cutout size 40mm

Door/ Cabinet magnetic sensor

Door magnetic sensor: Connect to [Sensor Gateway] [DS - 1 port, 6 core 1 (orange) and core 2 (orange - white)]





door magnetic sensor Orange, orange - white (no specific order)

Cabinet magnetic sensor: Connect to [Sensor Gateway] [DS - 2 port, core 3 (blue) and core 4 (blue - white)]





蓝蓝白(不分顺序)

Bathroom SOS

Bathroom SOS panel: Connect to [Sensor Gateway] [SOS] interface 7






NC-blue COM-brown

Room plate


Connect to [Sensor Gateway] [STA] interface 8






Doorbell

Just like the door plate, connect to [Sensor Gateway] [STA] interface. 8



Wiring in the Distribution Box



povodo品为道

Next Generation Smart Hotel Solutions



Scan the WeChat QR code for more information.

After - sales contact number: 400-100-5151

www.povodo.com V2.0.240522